

EH7000-3R

A007_0918

Eliminator® II desiccant dryer

Perfect for body shops with high levels of contamination



Features & Benefits

- Designed to provide continuous dry, oil-free air to -40°F dew point
- 3 in 1: Activated carbon pre-filter for superior oil vapor removal and built-in final filter with contained desiccant cartridge, no desiccant dust migration
- Largest 0.01 micron coalescer on the market
- Tool-less spin on/spin off elements for easy maintenance, comes with two (2) PB-004 brackets for easy mounting
- Inverse Flow® Technology, low pressure drop design
- High flow 3/8" NPT relieving regulator
- Automatic drain on first stage, manual petcock drains on second and third stages

1st Stage Replacement Element: 4P-060
2nd Stage Replacement Element: 3C-090
3rd Stage Replacement Element: DE401

Specifications

<i>Dryer Design</i>	Manual, Desiccant
<i>Recommended Temp</i>	100 °F
<i>Maximum Pressure</i>	150 PSIG
<i>Dryer Capacity</i>	-40 °F
<i>Filter Capacity</i>	0.01 micron and larger Activated Carbon Oil Absorption to 0.003 ppm
<i>Flow Capacity</i>	30 SCFM at 100 psi
<i>Differential Pressure</i>	<5.0 PSID at rated flow
<i>Height</i>	17.0"
<i>Width</i>	16.0"
<i>Depth</i>	4.75"
<i>Weight</i>	20 lbs.

Applications

- Ideally used in prep stations and paint booths to remove water, dirt, oil, and water vapor

CA PROPOSITION 65 WARNING



WARNING: Cancer and
Reproductive Harm
www.P65Warnings.ca.gov/product



(800) 521-9200



www.driair.com | www.rti-pbe.com



@RTiPBE



@rti_pbe



Installation & Operation

1. Install the unit with the air flowing in the direction indicated by the arrows on your unit (usually left-to-right).
2. Install the unit at the paint booth.
3. Install the supplied drain hose kit in your 1st stage auto drain (long hex at bottom of bowl).
4. Use the supplied brackets to support your unit from the wall of the booth.

Maintenance

1. Close the inlet valve and relieve the air pressure prior to servicing. Clean and inspect all parts prior to installing new elements and replace as necessary. *Note: Refer to Auto Drain maintenance sheet for information on the 1st stage float drain, if needed.*
2. Replace the 2nd stage desiccant cartridge when the color indicator changes from a light blue to purple-pink. If you notice an oil film on the old desiccant element or find liquid water in the bowl, it is time to change the 1st stage element as well.
3. After changing the 2nd stage element, the moisture indicator paper should change back to blue after flowing dry air past it for an hour. If it does not, change the paper also (supplied in bag with element).
4. Change the 1st stage element if the 2nd stage is failing more often than usual, or if the green pressure indicator on the top of the 1st stage turns to red. It should be changed at least one time every 6 months.

EH2500

Single-stage, stand alone desiccant dryer with brackets, sight glass and indicator.

Replacement Element:
DE401



E4000/E4000-3R

E4000: 1/4" regulator/gauge assembly and differential pressure indicator

E4000-3R: 3/8" regulator/gauge assembly and differential pressure indicator

Replacement Elements:
1st stage: 4P-060
2nd stage: DE401



EH4000/EH4000-3R

EH4000: 1/4" regulator/gauge assembly

EH4000-3R: 3/8" regulator/gauge assembly

Replacement Elements:
1st stage: 4P-060
2nd stage: DE401



EH7000-3R

Largest 0.01 micron coalescer on the market, featuring heavy duty design for high contaminate systems.

Replacement Elements:
1st stage: 4P-060
2nd stage: 3C-090
3rd stage: DE401



CA PROPOSITION 65 WARNING



WARNING: Cancer and Reproductive Harm

www.P65Warnings.ca.gov/product



(800) 521-9200



www.driair.com | www.rti-pbe.com



@RTiPBE



@rti_pbe

